


INSTRUCTION MANUAL

Z500
EP 1/10 SCALE ONROAD **NATRIX G**



SERPENT

INTRODUCTION

Thank you very much for selecting this Serpent rc car and thus become a member of the ever growing worldwide Serpent racing family. Serpent started in 1980 and has been growing its product-line and fan-base ever since.

The Serpent Natrix 750-E is a state of the art electric powered 1/10 scale onroad racing car. The assembly manual will guide you through all the steps to complete the car, so you can hit the track with a good base-set-up soonest. The Serpent design department succeeded to create a superbly performing car combined with ease of assembly and maintenance. The high quality standards of all parts and hardware will make racing your Serpent car a very rewarding activity !

Through our team, website and social media we will keep you up-to-date on all developments of the Serpent cars. We hope to meet you on the track and through our various media!
Enjoy the drive !

Team Serpent

Multiple World Champions

INSTRUCTIONS

Serpent's long tradition of excellence extends to the instruction manuals, and this instruction manual is no exception. The easy-to-follow layout is richly illustrated with 3D-rendered full-color images to make your building experience quick and easy. Following the instructions will result in a well-built, high-performance race-car that will soon be able to unleash its full potential at the racetrack. The kit includes bags, with bag numbers, which refer to the same step in the manual. Open only the indicated bag(s) per step and finish that part of the assembly. Remaining parts will be needed later on in the assembly process.

PLASTIC PARTS

The Serpent moulded parts are very durable and hard. When assembling longer screws in new composite parts, make sure to use new hex bits in your (power) tools. Pre-threading also helps to avoid screw damage.

SETUP

In certain assembly steps you need to make basic adjustments, which will give you a good initial setup for your Serpent Natrix 750-E. Fine-tuning the initial setup is an essential part of building a high-performance racecar like your Serpent Natrix 750-E.

EXPLODED VIEWS AND PARTS LIST

The exploded views of the Serpent Natrix 750-E are located in the back of the manual. The exploded views show all the parts of a particular assembly step along with the Serpent part number and hotlink to the Serpent website. Part numbers in orange indicates that this part is an optional. Optionals part names and numbers are showed below.

CUSTOMER SERVICE

Serpent has made a strong effort to make this manual as complete and clear as possible. Additional info may be published in our website: www.serpent.com or you may ask your dealer or the Serpent distributor for advice, or email Serpent direct: info@serpent.com. The Serpent Facebook, Twitter and Youtube pages give additional means of support and communications.

SAFETY

Read and take note of the 'Read this First section' before proceeding to assemble the car-kit. This car-kit is intended for persons aged 16 or older.

READ THIS FIRST!

- This is a highly technical hobby product, intended to be used in a safe racing environment. This car is capable of speeds in excess of 80 km/h or 50mph. Please follow these guidelines when building and operating this model.
- Parental guidance is required when the builder/user of this car is under 16.
- Follow the building instructions. If in doubt, contact your dealer or importer.
- Be sure to use the proper tools when assembling the car. Always exercise caution when using electric tools, knives and other sharp objects.
- Be careful when using liquids like lubrication oil, fuel or glue. Do not swallow.
- Follow the manufacturer's instruction in case you experience irritation after using the product.
- Be careful when operating the car. Stay away from any rotating parts such as wheels, gears and transmission. Stay away from motor, engine and exhaust pipe system or speedo during and immediately after use, as these parts may be very hot. We advise to use protective hand gloves.
- Only operate this car in a safe environment, like a special racing track or a closed parking lot. Avoid using this car on public roads, crowded places or near infants.
- Before operating this car, always check the mechanical status of the car. Also check that the transmitter and receiver frequencies correspond and are not used by any other racer at the same time. Check that the batteries of the transmitter and receiver are fully charged.
- After use, always check all the mechanics of the car. We advise to clean the car immediately after use, and inspect the parts for wear or fractures. Replace when necessary. Do not use water, methanol, thinner or other solvents to clean the car.
- Empty the fuel tank (depending on model) if needed and disconnect the receiver battery.
- Store the car in a dry and heated place to avoid corrosion of metal parts.
- Avoid using this car in wet conditions as the water will cause corrosion on the metal parts and bearings and these parts will cease to function properly. If driven in the wet, ensure that all the electric equipment is waterproofed and after use, that all moving parts are dried immediately.

CONTENTS

• FRONT DIFF ASSEMBLY	4
• REAR ASSEMBLY 1	6
• MOTOR MOUNT ASSEMBLY	12
• REAR ASSEMBLY 2	14
• FRONT ASSEMBLY	16
• STEERING ASSEMBLY	23
• CENTER ASSEMBLY	25
• BUMPER/SHOCKTOWER ASSEMBLY	28
• SHOCK ASSEMBLY	30
• EXPLODED VIEWS	40
• TEAM SERPENT NETWORK	48



LINES DESCRIPTION

Each step contains a variety of numbers, lines, and symbols. The numbers represent the order in which the parts should be assembled. The lines are described below.



Step number; the order in which you should assemble the indicated parts




Length after assembly



Assembly path of one item into another



Group of items (within lines) should be assembled first



Direction the item should be moved



Glue one item to another



Press/Insert one item into another



Connect one item to another



Gap between two items

ICONS DESCRIPTION

Each step contains a variety of symbols described below.



Carefull, read and check very well.



Apply a small amount of cyano glue. Use wear protection for eyes and hands.



Detail view to explain assembly or order of parts better.



Default set-up: This symbol indicates the default setup.



Grease: apply a small amount of grease to the parts shown.



Silicone grease: apply a small amount of grease to the parts shown.



Left and right parts should be assembled in the same way.



Thread lock: apply a small amount on the parts shown. Before to apply the threadlock, make sure to degrease the parts very well, as otherwise the threadlock will not work.



Silicone oil: use the indicated silicone oil for the shocks and differentials.



Parts or items not included in the kit.



Optional part, not standard in the kit.

FRONT DIFF ASSEMBLY

750e
NATRIX

Serpent


STEP 1

FRONT DIFF BAG

1.1



1.2



1.75x8.5

STEP 2


2.1

Add just enough oil to cover the large gear before assembling the small satellite gears and cross pins.

For the correct cst value please check the default setupsheet.



2.2



STEP 3**3.1**

Fill the differential with silicone oil 1 mm above the crosspin, do NOT overfill. For the correct cst value please check the default setup sheet.

SO

**3.2**


Add the big gear.

**STEP 4**

Mount the diff top-case on the lower case, make sure to follow below Detail View, and tighten the screws.

M2.5x10**HOW TO CLOSE THE FRONT DIFF**

The front diff top case has two protrusions (see below picture in red) to hold the geardiff shafts in the correct position. The two protrusions press on the upper shaft and thus secure the shafts in position.



M2.5x10
STEP 5

1- Allow the excess of oil to escape through the escape hole.

2- Close the hole with the 3x3 setscrew. Tighten carefully.

3- In case the diff feels too hard remove the M3x3 set screw and let some oils to escape and close again. Tighten carefully.

M3x3

M3x3


REAR ASSEMBLY 1

750e
NATRIX

Serpent


STEP 6

BAG 1






STEP 7

7.1



STEP 8


7.2

M3x8



M4x4

STEP 9





BRC 2









M3x6

STEP 10**6.1****6.2**



2x12

STEP 11**STEP 12**


STEP 13 BRG 3**6x12x4****2.5x12****M5x4****R5**



STEP 14**STEP 15****15.1****15.2**

STEP 16 BRG 4




OPT 804505 MOTOR PLATE 1/8 S750E



STEP 17**OPT 804512 SPUR GEAR 36T STEEL M1****804513 SPUR GEAR 38T STEEL M1****804515 SPUR GEAR 42T STEEL M1****804516 SPUR GEAR 44T STEEL M1****904178 SPUR GEAR 56T 988E****904179 SPUR GEAR 57T 988E****904180 SPUR GEAR 58T 988E**

R5



M3x5




M4x4




2.5x10

STEP 18 BRG 5



18.1



18.2



18.3




10x15x4



2x10

M3x3

STEP 19




STEP 20



M3x8





M3x6



M3x16


FRONT ASSEMBLY

STEP 21 BRG 6




M3x6

STEP 22




M3x6




M3x12

STEP 23



STEP 24












M2.5x4

M3x12




M3x4

STEP 25

26.1**26.2**STEP 26 **BAG 7**

STEP 27**STEP 28****28.1****28.2**

STEP 29 BRG 8



M3x8





3x6x0.5








3x6x1

STEP 30



M3x4

STEP 31

31.1**31.2****46.3**

M3x10



3.2x7x0.5




Nylock Nut M3




M3x3




2x10



10x15x4





M3x5




M3x6

STEP 32





STEP 33 BAG 9

33.1



33.2



M3x6



3x6x0.5





M3x6





4X7X2.5




3x5x1

STEP 34**34.1****34.2**

35.1



35.2




M3x6



M3x8




M3x10



3x6x6





M3x6




M3x6


STEP 36 BAG 10

36.1**36.2**




M3x5




M3x6



M3x8

STEP 37**STEP 38**


M3x6



M3x14



M3x6



M3x8





M3x10

BUMPER/SHOCKTOWER ASSEMBLY

750e NATRIX



STEP 39 BAG 11



M3x8





M3x6




Nylock Nut M3


STEP 40







M3x6



M3x8




M3x10

STEP 41**STEP 42**

STEP 43 SHOCK BAR

43.1



43.2



STEP 44

44.1



! For the correct piston holes please check the default setupsheet.

44.2



R2.3

STEP 45

45.1

Push the shock top and the membrane into the shock cap.



45.2

1- Fill up with silicone oil fully using the silicone oil supplied in the kit. For the correct cst value please check the default setup sheet.

2- Extend the shockrod fully

3- Move the shockrod slowly up and down to let ALL air bubbles escape.


4- Close top only 3/4.



45.3


1-Bleed: push the shockrod all the way in slowly, to allow excessive oil to escape.



2- Close completely the shock cap.





STEP 46


Assemble the spring and spring-cup (align correctly) to complete the shock.



STEP 47**STEP 48**




OPT 804505 MOTOR PLATE 1/8 5750E




M4x4



M3x10

STEP 50

OPT 804521 WHEELIEBAR SET S750E




3x6x2



3x6x3



6x8x0.3




6X10X3 Flanged



Nylock Nut M3



M3x6







M3x8




M3x20

OPT 804521 WHEELIEBAR SET S750E



M3x5





M3x8




M3x5

OPT 804353 RIM COVER FR 748 (2)
804354 RIM COVER RR 748 (2)



STEP 51


Nut M4
Flanged

STEP 52

Body clip mid

INDEX

DEFFERENTIAL EXPLODED VIEW	41
SHOCK EXPLODED VIEW	42
REAR EXPLODED VIEW	43
FRONT EXPLODED VIEW	44
CENTER EXPLODED VIEW	45
BUMPER SHOCKTOWER EXPLODED VIEW	46
FINAL EXPLODED VIEW	47




804391 Diff set rr 748 V2

804440 Diff set rr 750 arrowspace magnesium

804450 Oneway diff fr S7XX


OPT



160142 Shock onroad big bore piston 1 hole (4)
 160143 Shock onroad big bore piston 2 hole (4)
 160144 Shock onroad big bore piston 4 hole (4)
 160148 Shock onroad big bore piston 1 hole LF (2)
 160149 Shock onroad big bore piston 2 hole LF (2)
 160150 Shock onroad big bore piston 3 hole LF (2)

160151 Shock onroad big bore piston 4 hole LF (2)
 160297 Spring grey TC
 160298 Spring black TC
 160299 Spring green TC
 160300 Spring white
 160301 Spring yellow

160302 Spring orange
 160304 Spring Pink
 160305 Spring blue
 160306 Spring purple
 160310 Spring-set L23 (5x2)
 160147 Shock onroad big bore bushing LF (4)




OPT

- 804194 Wheel hexagon +1mm (4)
- 804195 Wheel hexagon -1mm (4)
- 804341 Antiroll bar 1.6 RR 748
- 804343 Antiroll bar 2.0 RR 748
- 804344 Antiroll bar 2.2 RR 748

- 804398 Pulley set low friction (6) 748 V2
- 804404 Driveshaft CVD alu (2)
- 804435 Wishbone insert carbon RR lw (2)
- 804446 Wheelaxle set CVD alu 0mm V2 (2)
- 804447 Wheelaxle CVD alu V2 (2)

- 804448 Wheel hexacon CVD 0mm V2 (2)
- 804449 Wheel hexacon CVD -1mm V2 (2)
- 804505 Motor plate 1/8 S750E
- 804512 Spur gear 36T steel M1
- 804513 Spur gear 38T steel M1

- 804515 Spur gear 42T steel M1
- 804516 Spur gear 44T steel M1
- 904178 Spurgear 56T 988E
- 904179 Spurgear 57T 988E
- 904180 Spurgear 58T 988E



804141 Antiroll bar FR 1.8mm
804143 Antiroll bar FR 2.5mm
804144 Antiroll bar FR 2.8mm
804194 Wheel hexagons +1mm clamp (4)


804195 Wheel hexagons -1mm clamp (4)
804363 Steeringblock lever carbon 748 (2)
804400 Suspension bracket FR brass
804404 Driveshaft CVD alu (2)

804434 Wishbone insert carbon FR lw (2)
804446 Wheelaxle set CVD alu 0mm V2 (2)
804447 Wheelaxle CVD alu V2 (2)
804448 Wheel hexacon CVD 0mm V2 (2)

804449 Wheel hexacon CVD -1mm V2 (2)
804450 Oneway diff fr S7XX

CENTER EXPLODED VIEW

Z50e




804193 Radiotray posts alu (2)
804361 Servosaver bottom alu


OPT

BUMPER SHOCKTOWER EXPLODED VIEW

S750e 




804293 Body support washers med + high (5+5)
804417 Diffusor S750
804521 Wheeliebar set S750E




OPT
804517 Pinion 22T steel M1,3
804518 Pinion 23T steel M1,3
804519 Pinion 24T steel M1,3
804520 Pinion 25T steel M1,3

TEAM SERPENT NETWORK

750 SPARE PARTS www.serpent.com/804013/spares/



750 OPTIONALS PARTS www.serpent.com/804013/Optionals/



SERPENT TOOLS www.serpent.com/product/Tools/



SERPENT MERCHANDISING www.serpent.com/product/Merchandising/



SERPENT WEBSITE AND BLOG

www.serpent.com
www.teamserpent.com
www.dragon-rc.com

SERPENT PROMO PAGES <http://promo.serpent.com>

SERPENT FACEBOOK GROUPS <http://promo.serpent.com/indexfb.htm>

SERPENT ADVANCED MANUALS <http://promo.serpent.com/sam/>

SERPENT SOCIAL MEDIA



www.facebook.com/teamserpentrc



www.youtube.com/user/SerpentMRC



www.twitter.com/SerpentMRC



www.plus.google.com/+SerpentModelcars/posts



www.weibo.com/teamserpent

INSTRUCTION MANUAL



#62941-1 Manual S750E

SERPENT